

# SILLA OPERATIVA

AIRE



**ACABADOS**



L a m b d a T r e s

# SILLA OPERATIVA

AIRE

## Tapicerías Grupo 1

mod. BALI



229



840



933



200



981



22



82



308



600



435



300



768

mod. BONDAY



169



9



1065



76



79



77



81



123



6098



5518



8078



5605



L a m b d a T r e s

# SILLA OPERATIVA

AIRE

## Tapicerías

### Grupo 1

mod. GOYA



840



640



32



205

mod. MICRO



330



510



209



350



200



100



522



218

mod. ARAN



229



840



933



200



300



430



861



065



40



600



515



715



L a m b d a T r e s

# SILLA OPERATIVA

AIRE

## Tapicerías Grupo 2

mod. NAPPEL



111



101



102



112



106



109



121



108



113



103



104



107

mod. ANKARA



3



4



3

mod. ZEN



18



6



10



10



21



11



13



27



31



L a m b d a T r e s

# SILLA OPERATIVA

AIRE

## Tapicerías Grupo 3

mod. **CONCEPT**



001



176



008



017



045



047



372



045



040



076



030



432

mod. **SANITEX**



258



269



452



030



031



702



032



033



021



051



094



052



L a m b d a T r e s

# SILLA OPERATIVA

AIRE

# Tapicerías Grupo 3

mod. XTREME



108



005



009



072



168



106



079



155



170



141



059



157



L a m b d a T r e s

# SILLA OPERATIVA

AIRE

## Tapicerías Grupo 4

mod. **MALLA**



M-001



M-002




P-001



P-002



M-003



M-004



P-003



P-004



M-005



M-006



P-005



P-006

mod. **PIEL**



L a m b d a T r e s